



NOTES:

1. TRANSVERSE TYPE C AND D JOINTS SHALL BE SAWS AS SOON AS CONCRETE CAN WITHSTAND RAVELING, JOINTS SHALL BE CLEANED AND FILLED WITH BITUMINOUS COMPOUND.
2. INSTALL TYPE E EXPANSION JOINTS AT INTERSECTIONS, AND AT END OF RADIUS'S AND AT BULB OF CUL-DE-SAC.
3. INSTALL TYPE E REINFORCED EXPANSION JOINTS AT PC & PT OF CURVES.
4. USE TYPE D JOINT AT END OF DAYS WORK AND PAVEMENTS GREATER THAN 6-INCHES.
5. USE TYPE L JOINT FOR PAVEMENTS GREATER THAN 6-INCHES.

2 FT MIN.

DRAWING NO. 304

CITY OF JACKSON, MISSOURI

K.A.P. 03/31/11  
Approved Date

PORTLAND CEMENT CONCRETE STREET STANDARD  
SAW CUT DETAILS

Revisions